

STOP SWITCH KIT - TURN/RELEASE TYPE

Code: ESS/1
Price:



TECHNICAL INFORMATION:

- Turn to Release Stop Switch
- PVC 3 Core Cable
- PVC Flex & Fittings
- All Necessary Fixings
- Drill Bit

STOP SWITCH KIT - PUSH/PULL TYPE

Code: ESS/2
Price:



TECHNICAL INFORMATION:

- Pull to Reset Stop Switch
- PVC 3 Core Cable
- PVC Flex & Fittings
- All Necessary Fixings
- Drill Bit

TEL: 0116 266 2241
E-Mail: sales@elevatorequipment.co.uk



FAX: 0116 266 2242
www.elevatorequipment.co.uk

STOP SWITCH KIT - FLAG INDICATOR TYPE

TECHNICAL INFORMATION:

Code: ESS/3
Price:



- Flag Indicator Stop Switch
- PVC 3 Core Cable
- PVC Flex & Fittings
- All Necessary Fixings
- Drill Bit

STOP SWITCH KIT - KEY TO RELEASE TYPE

TECHNICAL INFORMATION:

Code: ESS/4
Price:



- Key to Release Stop Switch
- PVC 3 Core Cable
- PVC Flex & Fittings
- All Necessary Fixings
- Drill Bit