


Universal aluminium traction sheave covers

Openings for rope jump off protection and inclined rope departures can be cut out on-site by the assembler.

Maintenance flap for technical inspection (EPS)

With cover sheet for traction sheaves without external bearing.




The traction sheave cover prevents that extremities are accidentally dragged in.




Advice:

Please note the advice "Protective covers on rotating parts" on page 155.



Mounting example for large traction sheaves
(For large traction sheaves an auxiliary holding device is included in delivery)




Mounting example for horizontal rope departure
*The entering points are additionally secured with protective covers.




Mounting example for inclined rope departure (shown here with additional diverter pulley protection [Art.no. 78626](#))

Scope of delivery



Suitable entering points overview




A detailed mounting instruction for the different traction sheave types is included in delivery.



© 10/2009

■ Traction sheave cover

The table below contains the order numbers for traction sheave covers. Therefore the exact traction sheave width and diameter have to be known.



Up to traction sheave width (mm):	Up to traction sheave width (mm):						
	360	390	420	450	480	510	540
55	78000	78001	78002	78003	78004	78005	78006
79	78014	78015	78016	78017	78018	78019	78020
103	78028	78029	78030	78031	78032	78033	78034
127	78042	78043	78044	78045	78046	78047	78048
139	78056	78057	78058	78059	78060	78061	78062
151	78070	78071	78072	78073	78074	78075	78076
163	78084	78085	78086	78087	78088	78089	78090
175	78098	78099	78100	78101	78102	78103	78104
187	78112	78113	78114	78115	78116	78117	78118
199	78126	78127	78128	78129	78130	78131	78132
211	78140	78141	78142	78143	78144	78145	78146
223	78154	78155	78156	78157	78158	78159	78160
235	78168	78169	78170	78171	78172	78173	78174
290	78182	78183	78184	78185	78186	78187	78188

Up to traction sheave width (mm):	Up to traction sheave width (mm):							
	570	600	630	660	720	780	840	970
50	78007	78008	78009	78010	78011	78012	78013	78196
74	78021	78022	78023	78024	78025	78026	78027	78197
98	78035	78036	78037	78038	78039	78040	78041	78198
122	78049	78050	78051	78052	78053	78054	78055	78199
134	78063	78064	78065	78066	78067	78068	78069	78200
146	78077	78078	78079	78080	78081	78082	78083	78201
158	78091	78092	78093	78094	78095	78096	78097	78202
170	78105	78106	78107	78108	78109	78110	78111	78203
182	78119	78120	78121	78122	78123	78124	78125	78204
194	78133	78134	78135	78136	78137	78138	78139	78205
201	78147	78148	78149	78150	78151	78152	78153	78206
213	78161	78162	78163	78164	78165	78166	78167	78207
225	78175	78176	78177	78178	78179	78180	78181	78208
280	78189	78190	78191	78192	78193	78194	78195	78209

