Lift Shaft Entrance Protection.

PATENT PENDING GB1507175.6





ONE MAN INSTALLATION!!

QUICK INSTALLATION AND REMOVAL!!



Elevator Equipment Limited, Unit 11-13 Parker Drive, Leicester LE4 0JP







Lift Shaft Entrance Protection.

PATENT PENDING GB1507175.6

SAFETY INSTRUCTIONS.

Always check **RAPID SYSTEM** products before installation.

Do not use damaged **RAPID SYSTEM** panels, **RAPID SYSTEM** posts, **RAPID SYSTEM** spring safety latches or **RAPID SYSTEM** U shape brackets

Always follow installation instructions carefully. Do not use in any other way other than shown.

Always use personal fall protection equipment during installation.

Never use installed RAPID SYSTEM Posts to tie off personal fall protection equipment.

Never use *RAPID SYSTEM* Posts to secure scaffolding.

When storing posts and panels use a suitable stillage to prevent accidental damage.

RAPID SYSTEM is designed for construction sites and should not be used to protect the general public.

Erected panels and posts should not be used for supporting construction materials in any way or form.

Elevator Equipment Ltd products liability only applies to combinations of Elevator Equipment Ltd. Products that are assembled according to **RAPID SYSTEM** instructions.

If the **RAPID SYSTEM** protection is subject to a high load e.g. after a fall, a qualified person must inspect the relative rapid panels and posts before being used again.

In case of any uncertainty contact Elevator Equipment Ltd.

IMPORTANT.

Always carry out a risk assessment and produce a method statement for the installation of *RAPID SYSTEM* prior to the commencement of any installation.

Always use personal fall protection equipment See Code of Practice PFPE ref. BS 8437

Elevator Equipment Limited, Unit 11-13 Parker Drive, Leicester LE4 0JP







Lift Shaft Entrance Protection.

PATENT PENDING GB1507175.6

INSTALLATION DETAILS.

Equipment Required.

Tape Measure
Magnetic Spirit Level
Scaffolding Spanner
PFPE (Personal fall protection equipment)
Hard Hat
High Visibility Vest or Jacket
Safety Boots
Gloves
Portable Safety Barrier

Always read the (SAFETY INSTRUCTIONS) before commencing installation.

Installation personal must be trained to fit RAPID SYSTEM Lift Shaft Entrance Protection.

Safety is your responsibility for yourself and others. Always follow your risk assessment, method statement and these safety instructions and installation guide.

Make sure all equipment is on site ready for installation. Once your PFPE has been fitted proceed as follows.

Check where posts and panels are to be erected and that there are no obstructions. i.e. building materials in the way. Contact the site foreman or manager if you have any problems.

Firstly erect a suitable barrier protection around the lift shaft entrance that you intend to install the **RAPID SYSTEM** Lift Shaft Entrance Protection.

Start from either left or right hand side of the lift shaft opening. **POST INSTALLATION** pictures show right hand post installation.

Position the **RAPID SYSTEM** post approximately 50mm from the side of the opening and face it so that the U shape bracket faces forward onto the landing. Please note the **RAPID SYSTEM** posts are handed.

Install the first post as shown on the (POST INSTALLATION page).

Use a magnetic spirit level to check the post is perpendicular.

The U shape bracket is always at the bottom of the post. When the panel is positioned into the U shape bracket it should be as close to the floor as possible. Adjust the U shape bracket if necessary.

Elevator Equipment Limited, Unit 11-13 Parker Drive, Leicester LE4 0JP







Lift Shaft Entrance Protection.

PATENT PENDING GB1507175.6

INSTALLATION DETAILS CONTINUED.

The spring safety latch is fitted higher up the post near the top of the panel. The latch must coincide with one of the vertical slot of the panel and be locked in the open position see **PANEL INSTALLATION.**

With the first post installed along with the bottom panel, now lift over the second post behind the bottom panel on either the left/ right hand side; lift up the left/right hand side of the bottom panel and position into the U shape bracket on the post. The toe board with the safety signs strip should be facing outwards from the lift shaft

Now locate the spring safety latch into the vertical slot on the panel and lock.

Install the second post as shown on the instructions on the post or see (POST INSTALLATION page).

Use a magnetic spirit level to check the post is perpendicular.

With both **RAPID SYSTEM** posts fixed and the bottom panel locked now lift up the second panel into the U shape bracket as per (**PANEL INSTALLATION** page).

Now locate the spring safety latches into the vertical slot on the panel and lock both sides.

Repeat the same procedure on each floor.

Elevator Equipment Limited, Unit 11-13 Parker Drive, Leicester LE4 0JP





Lift Shaft Entrance Protection.

PATENT PENDING GB1507175.6

POST INSTALLATION

Please follow the pictures below.


Maximum out of alignment from perpendicular 1.5 degrees.

Closed Height: 2 Metres

Maximum Extended Height: 3.4 Metres

Use magnetic spirit level to ensure post is perpendicular.

Weight of **RAPID SYSTEM** post is 9.5kg.



PRESS RELEASE BUTTON, LIFT UP SAFETYSLEEVE



HOLD LOWER POST TO CEILING AND PULL HANDLE OUT. POSITION MAGNETIC SPIRIT LEVEL.



HOLD INNER POST AND RAISE TO FIXED HEADER. WHEN IN THE CORRECT POSTION, PULL DOWN ON HANDLE TO LOCK.

NOW LET SAFETY SLEEVE DROP OVER LOCKING RING AND ENGAGE RELEASE BUTTON.

To uninstall **RAPID SYSTEM** post.

Press release button. Slide safety sleeve up the handle, press handle towards post and swing locking ring down.

post has been installed.

Pull handle outwards from post to release, and with opposite hand slide inner post down into lower post. For safety, pull handle towards post and refit locking ring and slide safety sleeve down to engage release button.

Elevator Equipment Limited, Unit 11-13 Parker Drive, Leicester LE4 0JP





Lift Shaft Entrance Protection.

PATENT PENDING GB1507175.6

POST INSTALLATION

IMPORTANT NOTICE

Incorporated in the design of the **RAPID SYSTEM** post is a force check flag. This is for the installer of the post to check that the correct force has been applied.

When the **RAPID SYSTEM** post has been installed correctly, the force check flag below should be at right angles to the post pictured below.

If the force check flag is not at right angles to the **RAPID SYSTEM** post.

Re-install the **RAPID SYSTEM** post.









Elevator Equipment Limited, Unit 11-13 Parker Drive, Leicester LE4 0JP

Tel: 0116 2662241, Fax: 0116 2662242 Email: sales@elevatorequipment.co.uk www.elevatorequipment.co.uk





Registered in England No. 4398327 Director: M Spencer C Moore

Lift Shaft Entrance Protection.

PATENT PENDING GB1507175.6

PANEL INSTALLATION

Please follow the pictures below.

SPRING LATCH OPERATION:



1. SPRING SAFETY LATCH IN THE LOCKED POSITION



2. PULL TO RELEASE SPRING SAFETY LATCH



3. TURN 45 DEGREES



4. RELEASE SPRING SAFETY LATCH TO LOCK PANEL

PANEL INSTALLATION:

Weight of **RAPID SYSTEM** panel is 16kg.



BEFORE YOU POSITION THE PANEL INTO THE BOTTOM U SHAPE BRACKET, PLEASE MAKE SURE THE SPRING SAFETY LATCH IS LOCKED INTO POSITION ONE AS ABOVE PICTURE 1

PLACE THE PANEL INTO THE BOTTOM U SHAPE BRACKET AND PUSH BACK TOWARDS THE POST.

RELEASE THE SPRING SAFETY LATCH AS PER PICTURE 2.

NOW COMPLETE AS PER PICTURE 3 AND 4 TO LOCK PANEL.
REPEAT SAME PROCEDURE FOR INSTALLING TOP PANEL.



Elevator Equipment Limited, Unit 11-13 Parker Drive, Leicester LE4 0JP

Tel: 0116 2662241, Fax: 0116 2662242 Email: sales@elevatorequipment.co.uk www.elevatorequipment.co.uk





Registered in England No. 4398327 Director: M Spencer C Moore

Lift Shaft Entrance Protection.

PATENT PENDING GB1507175.6

TEST CERTIFICATION



Barbot Hall Industrial Estate

Lloyds British Testing Ltd Jnit 4E, Cornish Way

UNIT D TREEFIELD IND. ESTATE

UNIT D TREEFIELD IND. ESTATE

RAPID EPS

Issued to:

GELDERD ROAD GILDERSOME

RAPID EPS

GELDERD ROAD

GILDERSOME

Issued by:

Location of equipment:

Report no:	2050/1422M
Your Order no:	311
Our Job no:	243525
Sheet no:	1 of 1

Your Order no: 311 Our Job no: 243525
--

Fax:

LS27 7JU

LS27 7JU

Rotherham Parkgate

S62 6EG

Report of Test and Thorough Examination of Lifting Plant and Equipment

This report complies with the requirements of the Lifting Operations and Lifting Equipment Regulations 1998, SI 2307

	Date of Test and Examination:	20/08/14									
Details of Test and Thorough Examination	Additional/Examination/Standards	REPORT OF LOAD TEST	TESTED TO BRITISH STANDARD	BSEN13374:2013 CLASS B	DYNAMIC LOAD APPLIED	@ BOTTOM OF TOE BOARD	@ 1080MM FROM ONE END	RESULT	MOVEMENT OF POSTS 5MM	DEFLECTION OF RAPID PANEL 46MM	
	Proof Load Applied: (Specify Units)	50 KG	BAG								
	Safe Working Load: (Specify Units)										
	Qty Tested and Examined:	-									
Description of Equipment		RAPID POSTS CODE NA001	SET @ 3.4MTR HEIGHT, FITTED WITH RAPID PANEL	2900 X 1066 RAPID CODE NA003 @ 2.4MTR CENTRES	SAME PANEL USED AS IN TEST 9A BATCH						
Identification Mark of the Equipment:		2 RAF	SET (2900	SAME						
		TEST 9B	ВАТСН								

The above equipment has been thoroughly examined, no defects found and is safe to operate



Name:

Vame and address of person authenticating and signing this report on behalf of

TEST ENGINEER





Signature:

Date of Report:

Sutten Coldfield, West Midlands, B74 4AB Company Registration No: 444099 VAT Reg. No: GB 729 2136 35 3RD OCTOBER 2014 Registered Office: Lloyds British Testing Ltd, Atlas House, 4-6 Belwell Lane, Four Oaks, Surier Coldfield, West Midlands, B74 4AB. Company Registration No Tel: +44 0870 197 5500 Fax: +44 0870 197 5506 email: sales@lloydsbritish.com web: www.lloydsbritish.com

Elevator Equipment Limited, Unit 11-13 Parker Drive, Leicester LE4 0JP



